

Support Devices

Device	Model	Version
Acer Iconia Tab 7	A1-713	4.4.2
Asus Nexus 7 (2nd Gen.)	Nexus 7	5.1.1
HTC 9060	HC3AHPN00008	4.4.2
HTC Butterfly	HTCBUTTERFLY	4.4.2
HTC Droid INCREDIBLE	ADR6410IVW	4.0.3
HTC EVO 3D	PG86100	4.0.3
HTC One	HTC6525LVW	4.4.2
HTC Rezound	HT1ANS206932	4.0.3
LG Nexus 4	NEXUS4	4.4.4
LG Nexus 5X	NEXUS5X	6.0.1
LG Optimus L7	LG-P705	4.0.3
LG Spectrum 2	VS930 4G	4.0.4
LG VS840	VS8404G	4.0.4
Motorola Droid Razr	Droid Razr	4.1.2
Motorola Droid Razr M	XT907	4.4.2
Motorola Droid Razr Maxx HD	Droid Razr Maxx HD	4.4.2
Motorola Moto X	XT1056	5.1
Motorola Moto X GEN2	XT1095	6.0.0
Samsung Galaxy	SCH-I185	4.0.4
Samsung Galaxy Nexus	GALAXYNEXUS	4.2.2
Samsung Galaxy Note	SGH-I717	4.0.4
Samsung Galaxy Note 3	SM-N9006	4.3
Samsung Galaxy S III	SCH-I535	4.1.2
Samsung Galaxy S2	SGH-T989	4.0.4
Samsung Galaxy S3	SGH-T999	4.1.1
Samsung Galaxy S3	GT-I9300	4.1.2
Samsung Galaxy S6	SM-G920T	5.1.1
Samsung Galaxy S6	SM-G9208	6.0.1
Samsung Galaxy S7	SM-G930T	6.0.1
Samsung Galaxy S7	SM-G930V	6.0.1
Samsung Galaxy Tab 10.1 LTE	SCH-I905	4.0.4
Samsung Galaxy Tab 2	SCH-i705	4.1.2
Samsung Galaxy Tab 2 7.0	GT-P3110	4.0.3
Samsung Galaxy Tab 3 10.1	GT-P5200	4.2.2
Samsung Galaxy Tab 3 7.0	SM-T210R	4.4.2
Samsung Galaxy Tab 3 8.0	SM-T311	4.2.2
Samsung Galaxy Tab 4 10.1	SM-T530NU	5.0.2
Samsung Galaxy Tab 4 7.0	SM-T230NU	4.4.2
Samsung Galaxy Tab 8.9	GT-P7310	4.0.4